



Subwoofer serie	CWP 10	CWP 12
Power rating RMS (Watt)	150	200
Power rating MAX. (Watt)	500	700
Nominal imp. Z (ohm/coil)	4	4
DC-resistance Re (ohm/coil)	3,1	3,1
Fs free-air resonance (Hz)	26,01	21,25
Qms	4,43	4,31
Qes	0,44	0,50
Qts (Qe // Qm)	0,40	0,44
X-max. (cm)	0,8	0,8
Cone-area sq. Cm	323,65	490,87
Vas (Liter)	60,29	145,13
Mms (gr.)	91,4	130,84
Cms (µM/N)	410	429
Bl (T/M)	10,28	10,45
mounting depth (inch)	5,3	5,8
mounting depth (cm)	13,5	14,7
mounting hole (inch)	9,4	13,6
mounting hole (cm)	23,8	28,8

VOLUME CALCULATION OF VARIOUS SPEAKER MODELS

When calculating volume, the length, width and height dimensions are always used.
Remember that the measurements used are always the inside measurements in cm.

Volume of cubical subwoofer cabinet:

Vol. = (L cm x H cm x B cm) : 1000 = litres

Volume of subwoofer cabinet with sloping side:

Vol. = ((Y + Z) x H x B) : 2000 = litre

The advantage of this calculation is that you can first determine what the maximum width and height measurements of the cabinet can be. Using the formula below, you can then calculate the depth.
The data required: Width (cm), Height (cm) and the recommended volume of the cabinet.

Depth (Y) upper side:

$Y = (1000 \times \text{Volume litres}) : (B \text{ cm} \times H \text{ cm}) - (H \text{ cm} : 4.1) = \dots \text{ cm}$

Depth (Z) lower side:

$Z = Y \text{ cm} + (0.49 \times \text{Height in cm}) = \dots \text{ cm}$

TAKE NOTE!

You have now calculated all the internal measurements. The material thickness has to be added to find the external measurements. Draw a construction plan in diagram form before you get started.

